

SURVEY CHECKLIST: *to be completed on site*****

- Points E/K to be fixed 40mm down from the top of the glazing bars at the dome.
- To measure EK you need line of sight between the points. To achieve this:
 - Remove the dome cap by unscrewing the spindle at the base of the dome.
 - Also, please accurately measure the dome diameter once it has been removed.
 - Dome Diameter.....mm
- Fit point A to the house wall just below the ridge. please confirm if this fitting is masonry or timber .
- All lower fitting points should be fixed to the middle of the vertical fascia,
- Intermediate points C/Q to be at midpoints of BD/PR.
- Points FD & NP to be set at 375mm away from the glazing bar.
- Fit point L to the midpoint of the fascia.

Confirmation required for the following:

- Colour of Fabric
- Colour of Fittings

Notes:

Survey points to be taken from point on conservatory where eye plates are to be fixed.

MARK ALL POINTS BEFORE COMMENCING SURVEY

Dimensions should be taken as accurately as possible ideally +/-5mm

Any queries regarding this please contact us on 01786 450083

Design Shows:
5 x Made to Measure InShade Sails - ISX - TBC
(Sails are shown in Ivory for design clarity)

Obstructions: Dome

Special Fittings: None

Some sails may require a colour matched seam, this will be confirmed on receipt of final dimensions.

t : 01786 450083 e : inshade@shadeplus.co.uk

Project: 72292-8265-Chittenden

Date: 08.07.20 Drawn: JH Check: MF

Required Dims :

Sail 01	Sail 02	Sail 03
AB	EF	EH
BC	FG	HJ
CD	GH	JK
DE	HL	KE
EA	LE	
		EJ
AC	EG	HK
AD	EH	
BE	FH	
CE	GL	

Sail 04	Sail 05
KL	KP
LJ	PQ
JM	QR
MN	RA
NK	AK
KJ	KQ
KM	KR
LM	PA
LN	QA

