

ROMO Ltd.  
 Oddicroft Lane  
 Sutton-In-Ashfield  
 Nottinghamshire  
 NG17 5FB  
 Tel. (01623) 750005

**DESPATCH NOTE**

**THE ROMO GROUP**

\_index\_EX299311

Page 1

**Invoice Address:-**

CARPET PROTECTION (CI) LIMITED  
 T/A CP INTERIORS  
 RUE DES PRES TRADING ESTATE  
 ST SAVIOUR  
 JERSEY JE2 7QN

Account **57744**

C135 (U) (0)

**Processing Instructions:-**

TINA X130

Piece	Gross	Nett	Ordered	Description	Cut
				<b>PLEASE CHECK AND EXAMINE ALL LENGTHS BEFORE CUTTING</b>	
5155583	A	2.0	2.0	1 RF W467/05 KIANA SOFT-GOLD	
		1.0	1.0	2 ROMO PREMIUM QUALITY TUB AD. 5KG	
<p>These goods are supplied subject to the Romo Terms and Conditions of Sale (as amended), copies of which are available on request in our Trade Price List or on the trade section of our website at <a href="http://www.romo.com">www.romo.com</a>.</p>					

RECEIVED

01 NOV 2024

SCANNED

Carrier	UPS (Channel Is)
Parcels	2
Despatch Date	29/10/24
Vetted	
Printed	29/10/24 11:26 am
Packed	Steven Brown

Customer Ref. SO16286 WISEMAN

**Despatch To:-**

CARPET PROTECTION (CI) LIMITED  
 T/A CP INTERIORS  
 RUE DES PRES TRADING ESTATE  
 ST SAVIOUR  
 JERSEY JE2 7QN

**Despatch Instructions:-**

Taken on 29/10/24 at 08:06 am by Tina Cottam (Email)

**EXPORT**

ORDER - EX299311

**9311 S18 29**

# THE ROMO GROUP

## Installation Instructions

Thank you for ordering our wallcoverings. Please do not cut or install until you have read these instructions carefully. For best results, we strongly recommend that a professional installer should hang these wallcoverings.

### Characteristics

- This wallcovering is a specialised product and must be handled with care.

### Before Installation

- Before cutting and hanging the wallpaper, ensure that all rolls have the same batch reference, are in good condition, with no variation in shade, and that no other faults are present. Please ensure that there are enough rolls to complete the job.
- Do not assume that the wallpaper will come off the roll the correct way up. Always refer to the pattern book or check with your retailer.
- Examination of the paper before hanging is the buyer's responsibility.

### Wall Preparation

- Walls should be clean, dry and even.
- Remove any old wallpaper and loose paint.
- Roughen painted surfaces with sandpaper.
- Scrape powdery, flaky surfaces. Absorbant surfaces should be prepared with an oil based primer ensuring it dries completely.
- New plaster should be allowed to dry out completely.
- Metallic effects can be damaged if high levels of alkaline are already present in the walls. Preparing the walls with an alkaline resistant primer should prevent any damage of this type.
- For best results, we recommend that the walls are cross lined using a good quality lining paper. Sizing the lining paper will aid adhesion. Lining should be allowed to dry completely before hanging the wallpaper.

### Installation

- This is a 'paste the wall' product. The decorator should paste the wall and not the back of the wallcovering.
- Romo's Premium Quality Tub Adhesive, or an equivalent good quality, solvent-free, fungicide protected, light grade adhesive should be used. Do not use self-mix adhesives. All purpose and heavy duty pastes are not suitable.
- Paste should be evenly applied to the wall to hang 1 length at a time, to an area slightly wider than the width of the roll.
- Lightly brush the back of beaded wallcoverings to remove any loose beads being careful to avoid beads getting into the paste.
- Butt joints and use a decorator's brush to smooth down the wallcovering, working from the centre to the edges to express air bubbles. NB. If this is a flocked or beaded wallcovering, use only a clean, soft roller NOT a decorator's brush.
- Avoid squeezing paste out of joints and ensure paste does not get onto the brush or roller.
- No paste should be allowed to come into contact with the surface and hands should be kept clean and dry whilst handling the wallcovering.
- Paste will damage the surface, particularly any flocked or beaded areas. The company cannot accept responsibility for marks or damage caused by paste.
- Should any paste have been allowed to come into contact with the surface, it should be lightly sponged whilst still moist, using a clean damp sponge.
- During hanging excess beads may become loose. Loose beads should not be considered a fault, as the glassbead pattern will remain intact.
- Trim top and bottom with a sharp knife or scissors.
- Dark coloured wallcoverings may need their edges coloured with a crayon of a similar tone to avoid white edges showing.
- Ensure wallcovering is firmly adhered as, in the event of fire, loose wallcoverings can contribute to the hazard.
- After hanging 2 or 3 lengths, inspect the result to ensure that no shading or other faults are present.

NO CLAIMS WILL BE ALLOWED FOR MORE THAN THREE DROPS/STRIPS INSTALLED ON THE WALL. WALLCOVERINGS ARE RETURNABLE WITHIN 30 DAYS OF INVOICE DATE, IN A SALEABLE CONDITION IN THE UNOPENED ORIGINAL WRAPPING. WE WILL NOT ACCEPT LABOUR CLAIMS UNDER ANY CIRCUMSTANCES.

If you have any questions before or during installation, please contact Customer Services.

This information has been supplied in good faith, but without guarantee, and on the understanding that the installer will have decorating knowledge to work with differing site and/or atmospheric conditions.