

## CARE GUIDE F1

For PVC coated upholstery fabrics.

design

### HIGH PERFORMANCE FAUX LEATHER MEETING HOSPITALITY/CONTRACT STANDARD.

Our range of high performance faux leathers are perfectly suited to high traffic areas in a wide range of contract, hospitality, healthcare and cruise ship interiors. These fabrics are fire retardant, hygienic, durable and easily cleanable as well as being eco-friendly, manufactured in Europe under some of the strictest environmental standards and fully REACH compliant.

### CARE GUIDELINES GENERAL RULES TO FOLLOW FOR REGULAR CARE.

- In general day to day cleaning requires little more than wiping down with a clean, damp cloth with regular cleaning recommended to keep the fabric looking good for longer.
- Clean spillages and stains by initially blotting up any excess liquid with a tissue, do not leave to dry onto the surface. Use a little fresh water and a microfibre cloth to gently clean taking care not to rub stain deeper into fabric.
- For stubborn or dried in staining use water with a little pH neutral liquid soap (max 5% solution), repeat if necessary.
- Using liquid soap and water can be one of the most effective cleaning methods. Caution should be taken not to over wet the fabric and ensure all soap residue is removed to avoid fabric discolouration and odour.
- After cleaning ensure fabric surface is left completely dry. Never soak or over wet the fabric.
- Clean up spills and stains right away, the longer stains are allowed to remain the more difficult they are to remove and can cause damage.
- Do not use abrasive cleaners, strong bleach, strong chemicals, toxic substances, acids, oils, strong solvents, wax or polish.
- Not suitable for dry cleaning or machine washing.
- Regularly brush using a soft headed brush to remove normal dust or gently vacuum away loose dirt before it becomes embedded in the fabric.
- Spillages of strong or neat alcohol if not cleaned immediately may cause damage to the fabric.
- Protect from excessive sunlight and avoid contact with strong heat.
- When dealing with any stain it is important to always test an inconspicuous area of the fabric first to ensure the treatment will not cause permanent damage. If in any doubt specialist upholstery cleaning advise should be obtained.

### DEEP CLEANING DISINFECTING YOUR FAUX LEATHER.

These fabrics have good antibacterial and antimicrobial properties which minimise the build-up and activity of bacteria and viruses, however if disinfection cleaning is required the following methods can be used:

- Antibacterial wipes and sprays suitable for upholstery can be used following manufacturers guidelines. Specifically this fabric has been tested using 'Clinell Universal Range of Disinfectant Wipes' and spray solution products.
- 5% bleach (sodium hypochlorite) solution. Please note excessive and prolonged use may cause colour fading over time.
- Steam cleaning can be used taking care not to exceed a contact temperature of 80 degrees centigrade.
- Alcohol disinfectant, 75% solution.

### IMPORANT

Although this fabric will resist most types of staining under normal contract conditions it does require regular care as described. Spills that are allowed to remain on the fabric for long periods of time can cause damage and in rare cases may not be completely removed.

Certain textile dyes such as those used in denim jeans can migrate onto the fabric, this can be especially visible on lighter colours. Heat and humidity can also contribute to this phenomenon and its irreversible. We are unable to accept responsibility for dye transfer caused by external contaminants.

All upholstery must have sufficient padding to support the fabric otherwise the fabric can stretch and become baggy. Damage to the fabric surface is likely if pulled over hard, exposed corners without adequate padding and protection.

We do not recommend and take no responsibility for the performance of the fabric when used for piping.

Our 'limitation of liability' as detailed on our price list applies.



easy clean



healthcare



waterproof



REACH



contract FR