

All dimensions to be recorded in mm and measured as accurately as possible (to minimum +/- 5mm).

C1/C2 = Distance from back space corners at top of fascia to middle of the ridge

C3/C4/C5/C6 = Distance from chamfer space corners at top of fascia to capping piece fitting point

Confirm if fitting to:
 UPVC Timber Aluminium Plasterboard

Confirm at end of the ridge if fitting to:
 Ridge underside House wall


Box gutter (check structure and mark location on sketch):
 Single Skinned Double Skinned Not applicable

Check how far in from corners you can place the fittings (measure to where the center of the fittings will go) 50 mm.

Take photos of the space, underneath the capping piece to confirm required kit and any obstructions.

Required dimensions in mm:

C1	1560	H1	2240
C2	1560	H2	2810
C3	1630	H3	55
C4	1630	H4	120
C5	1635		
C6	1635		



- Mark any obstructions and take their dimensions
 - Box Outs
 - Tie-Bars
 - Openers
 - Lights
 - Fans
 - Corner pieces
- None

Obstruction dimensions

- O1 = Distance down from middle of ridge to opener
- O2 = Distance up from top of fascia to opener
- T1/T2 = Distance up from top of fascia to bottom/top of tie-bar strut/bracket
- L1/F1 = Distance up from top of fascia to centre of light/fan
- L2/F2 = Drop of light/fan from ridge to centre of light/fan blades
- L3/F3 = Diameter of light/fan blades

Required dimensions in mm:


Y1	2085
Y2	2930
Y3	2090
X1	1175
X2	1175
X3	1175
X4	2885

Required dimensions in mm:

D1	3550
D2	3550
D3	2175
D4	2175
R1	1495

Obstruction dimensions in mm:

T1	N/A
T2	N/A
O1	N/A
O2	N/A
L1	N/A
L2	N/A
L3	N/A
F1	N/A
F2	N/A
F3	N/A
B1	N/A
B2	N/A



□ Take distances between centers of all glazing bars and mark this on the plan view layout (measure only half if symmetrical).

□ Check glazing bars width70..... mm.

Notes:

.....

.....

.....

.....

.....

